User Replaceable Items effective 12/01/2005

ELP-3500

Description	Part Number
AC Power Cable	201 7328
A/V Cable (RCA Plugs)	201 6048
MAC Adapter	202 3095
Lamp (ELPLP02)	103 1106
Remote Controller	103 1082
Lens Cap with String	103 1519
Computer Cable (VGA Cable)	202 2604
PS/2 Mouse Cable	202 2606
Mac Mouse Cable	202 2607
Audio Cable (3.5mm plugs)	202 2956
User's Manual	400 6222

Order user replaceable parts from an Epson authorized parts distributor.

---- or ----

Locate an Epson Authorized Service Center to order user replaceable parts by using the “Help me find…” tool in the right column of the Epson Support home page.